

~ Arthur **Queue** ~

We use 3x8/10 metal-in-wood or metal-in-synthetic for the tightest connection of buttpiece and shaft.

When you connect shaft and buttpiece we highly recommend to **turn the shaft first counterclockwise until you feel a little „click“. Now you can close the connection.**

If you use our extension we recommend the same procedure!

